



General
This plan provides information in respect of planning permission 1412/146/14 (Residential) and planning permission 14649/14/14 (Residential) for the proposed development. The plan is intended to be used in conjunction with the Arboricultural Method Statement and the Arboricultural Method Statement. The plan is intended to be used in conjunction with the Arboricultural Method Statement and the Arboricultural Method Statement.

Site Boundary
Indicative boundary

Statutory Designations (trees)
High Conservation Woodland Area

Site Hoarding
Line of site hoarding within RPA

Arboricultural Method Statement
The primary purpose of this plan is to aid the preservation of retained trees through setting out the appropriate working practices, construction techniques and tree protection measures that are to be adopted when construction works are undertaken in the vicinity of trees. The methodology of this Tree Protection Plan is based on the Arboricultural Method Statement. The plan is intended to be used in conjunction with the Arboricultural Method Statement and the Arboricultural Method Statement.

Work stage and scope of arboricultural monitoring

Work Stage	Scope of monitoring
Pre-construction meeting	Attend site, discuss and agree monitoring strategy with the production strategy with Site Manager. Check and confirm details of monitoring strategy with Site Manager.
Tree Protection Barriers and Ground Protection	On installation of tree protection barriers, check and confirm details of monitoring strategy with Site Manager. Check and confirm details of monitoring strategy with Site Manager.
Ground protection prior to installation of services and drainage	Attend site and check details of monitoring strategy with Site Manager. Check and confirm details of monitoring strategy with Site Manager.
Installation of foundations, walls or removal of hard surfacing	Attend site and discuss methodology of works with Site Manager. Check and confirm details of monitoring strategy with Site Manager.
Unexcavated works within the RPA or Construction Exclusion Zone	Attend site and discuss methodology of works with Site Manager. Check and confirm details of monitoring strategy with Site Manager.
Excavated works	Attend site and discuss methodology of works with Site Manager. Check and confirm details of monitoring strategy with Site Manager.
Final tree inspection and Tree Works	Attend site and discuss methodology of works with Site Manager. Check and confirm details of monitoring strategy with Site Manager.
Tree Works	Attend site and discuss methodology of works with Site Manager. Check and confirm details of monitoring strategy with Site Manager.
Landscaping	Attend site and discuss methodology of works with Site Manager. Check and confirm details of monitoring strategy with Site Manager.

tree:fabrik
Lenton House
Lenton Street
Alton, Hampshire
GU34 1HG
T: 01420 593250
F: 01420 544243
E: alan@treefabrik.com

Project
LATCHMERE HOUSE
RICHMOND

Drawing
TREE PROTECTION & ARBORICULTURAL
METHOD STATEMENT - CONSTRUCTION

Scale
1:500

Date
NOV '15

Drawn
AR

Revision
Revision

Drawing No.
if 91361/TPP/302

Drawing sheet size - A1
mm 5 10 15 20 25 30 35 40 45 50

Scale
1:500

